N	Л	٦	7
$\mathbb{V}$	U		
Virtual	Univ	ersi	ty

## CS609-System Programming Solved MCQ(S) From FinalTerm Papers BY Arslan

V-U

For Updated Files Visit Our Site : <u>Www.VirtualUstaad.blogspot.com</u>

Updated.



In the Name of Allāh, the Most Gracious, the Most Merciful

## **Final-Term Papers Solved MCQS with Reference**

- 1. DOS command \_\_\_\_\_\_ gives the status of the memory and also points out which memory area occupied by which process.
  - ≻ <mark>mem/d</mark>
  - ⊳ mem/e
  - ▶ mem/m
  - None of the Given

2.To store each character in keyboard buffer \_\_\_\_\_ bytes are required.

PG # 13

۶	2	PG # 54	
۶	4		
۶	6		
۶	8		

## بری صحبت سے تنہائی بہتر ہے اور تنہائی سے نیک صحبت بہتر ہے

3. The interval timer is used to divide	an input frequency.
> True	PG #68
> False	
4. The printer interface uses the	
> IRQ 6	
> IRQ 7	PG # 95
> IRQ 1	
None of given options	
5.You can send bits in paralle	l communication between two PC's at a time.
> 2	
> 4	
> 6	
> 8	
6.In UART the line control register si	gnify the
<ul><li>Word size and length of stop bit</li></ul>	S
> parity check and parity type	
<ul> <li>Control bit</li> </ul>	
> All of given	PG # 114

اللہ کا خوف سب سے بڑی دانائی ہے

7.The bit 0	of Line control register in UART, if set indicates that the DLL and DLM will act as the divisor register.
▶ 1	
> 3	
> 7	PG # 114
8.Int 14H	can be used to set the line parameter of the UART or COM port.
Service # 0	PG #119
Service # 1	
> Service # 2	
Service # 3	
9 is used t	o read time from RTC.
> 1A/02H	PG # 137
≻ 1A/03H	
≻ 1A/04H	
➢ 1A/05H	
/ 1120011	
10 The	signals are used by verious devices to request a DMA energian
10.The	signals are used by various devices to request a DMA operation.
> DREQ	PG #186
≻ REQ	
> DRE	
<ul><li>None of the gi</li></ul>	ven
i i i i i i i i i i i i i i i i i i i	
4 A	
ہو جاتا ہے	ایماندار کو غصبہ دیر سے آتا ہے اور جلدی دور ہ

11	.DMA works in modes.		
>	2		
>	3	PG #188	
>	5		
>	7		
<mark>dma i</mark>	Modes Block Transfer, Single Trans	er, Demand Transfer	
12	DMA Request register can be use	to simulate a DMA request through software in case of	
۶	I/O to memory transfer		
>	None of the given		
>	Memory to memory transfer	PG #192	
>	Memory to I/O transfer		
13	are the circular division	f the disk.	
>	Tracks	PG #201	
>	Sectors		
~	Blocks		
~	None of given		
Track	s are the circular division of the d	sk and the sectors are the longitudinal division of the disk	
14	.Blocks are		
>	Sectors per track	PG #202	
4	Track per sector		
>	Cylinder per track		
>	None of the given		
بنو	ی سے پریشان مت	زندگی میں کامیابی کا یہی راز ہے کہ پریشانیو	

15.Last bytes of data part in partitioning	table are the partition table signature.
> 2	PG #218
▶ 4	
≻ 6	
≥ 8	
16.Information about further partitioned drive	es is available at physical block of extended partition.
> First	PG #222
> Second	
> Third	
> Fourth	
17 will be used to get drive parame	ters.
➢ Int 13H/42H	
> Int 13H/48H	PG #238
➢ Int 13H/66H	
➢ Int 13H/66H	
18.Inside a boot block operating system name	occupies bytes.
> 3	
≻ 5	
➢ 8 Not sure	
> 11	
، پر قابو رکھنا ہے	دنیا کی سب سے بڑی فتح نفس

- 19.A programmer wants to access the DPB(Drive Parameter Block) for C drive using undocumented service 21H/32H, what he should place in DL register \_\_\_\_\_?
- > 0 PG #249
- > 1
- ≥ 2
- ≻ 3

```
DL – 0 for current Drive
```

20.Blocks for FAT can be accessed using \_\_\_\_

- > BPB
- > DPB
- > FCB
- Both BPB and DPB.

21.In main memory smallest addressable unit is \_\_\_\_\_

## > <mark>Byte</mark>

- Nibble
- > Word
- None of the given

22.Using the root directory entry and the \_\_\_\_\_, we can access the contents of File.

PG # 241

- Reserved Blocks
- Number of FAT copies
- File Allocation Table(FAT)
- None of the given

23.If a file is having more than one cluster then it will be managed by \_\_\_\_

- ► FAT
- > BPB
- > DPB
- None of the given

24. Practically in FAT 32, total number of entries are \_\_\_\_\_.

- $> 2^{26}$
- > 2<sup>28</sup>
- $> 2^{30}$
- > 2<sup>32</sup>

25.\_\_\_\_\_ keeps the back up of its boot block.

- ➢ FAT 12
- ➢ FAT 16
- **FAT 32**
- None of the given

26.NTFS can store file name in \_\_\_\_\_ form.

> UNICODE

**Click Here For More Detail** 

- ➢ Both ASCII and UNICODE
- None of the given
- > ASCII

27.FAT based file system can store file name i	n form.
> ASCII	
> UNICODE	
> Both ASCII and UNICODE	
<ul><li>None of the given</li></ul>	
28. The LSN of first logical sector of NTFS par	rtition is
	6 # 240
<ul> <li>▶ 1</li> <li>▶ 2</li> </ul>	
₽ 2 ₽ 3	
29.To minimize defragmenter is us	sed.
> Seek time PG	# 316
<ul> <li>Access time</li> </ul>	
<ul> <li>Rotational delay</li> </ul>	
<ul><li>Both seek and access time</li></ul>	
30.In memory map of first 1 MB of RAM, the	higher is called system memory.
▶ 64 KB	
	# 317
➢ 640 KB	
<ul><li>None of the given</li></ul>	
	t 640KB is called conventional RAM and the higher 384KB is called system
emory.	حصو با انسیاری او د ایماری دو تو

- 31.Extended memory can be accessed in \_\_\_\_\_ mode.
- Real
- Protected
- Both real and protected
- ➢ None of the given

32.Extended memory can be accessed only after installing the driver \_

- ► EMM386.EXE
- > HIMEM.SYS
- > IO.SYS
- None of the given
- 33.DOS uses \_\_\_\_\_ memory allocation system.
- Contiguous

PG # 325

PG # 326

PG # 318


- Non Contiguous
- Both Contiguous and Non Contiguous
- None of the given

34.In protected mode segment register will be called \_\_\_\_\_

- > <mark>Selector</mark>
- Descriptor
- > IDT
- Both Selector and Descriptor

35. There are Control registers in 80386 and above systems.
> 2
PG # 331
> 8
▶ 16
36.If the CHS (cylinder, head, and sector) address of a disk is known it can be translated in to the address and vice versa.
> Logical
> LBA PG # 213
> Physical
> None of the Given
37 is a data structure maintained by DOS in the boot block for each drive.
> DPB
> BPB         PG # 242
≻ FCB
None of the Given

BIOS parameter block



38.	System Stores the DPBs (Drive Parameter Block) for different drives in the form of
>	Chain / link list
۶	Array
۶	Table     Not sure
۶	None of Given
39.	The extension of a compiled TSR (Terminate and Study Resident) program should be
۶	.EXE
۶	.COM
	.CPP
۶	.C
40.	. A single interrupt controller can arbitrate among different devices.
	> 4
	> 6
	> 8 PG # 47
	> 10

41. The microprocessor package has many signals for data. Below are some in Correct priority order (Higher to Lower).

- ➢ Reset,Hold,NMI,INTR
- > NMI, INTR, Hold, Reset PG # 46
- > INTR,NMI,Reset,Hold
- > None of the Given

42	.A standard PC can have	_PPI.
>	1	
>		
≻		
	16	
\	dard DC can be a 4 DDI named I	
	dard PC can have 4 PPI named L	
43	.BIOS DO NOT support	
۶	LPT1	
۶	LPT2	
۶	LPT3	
≻	LPT4	
44	is used to set date.	
۶	1A/02H	
۶	1A/03H	
۶	1A/04H	
۶	1A/05H	PG # 139
45	.If real time clock interrupts micr	oprocessor then interrupt will occur.
>	13h	
۶	17h	
≻	70h	
≻	71h	

46.	is LED control byte.	
>	0xF3	
>	0xED PG # 181	
>	0xE5	
≻	0xFF	
47.	The DMA requests to acquire buses through the signal.	
۶	HOLD PG # 186	
>	ACR	
>	ACK	
۶	All of the given	
48.	will specify if the next DMA transfer will happen as a single transfer, block transfer or demand transfer	
≻	DMA Request register	
۶	DMA Mask register	
>	DMA Mode register	
۶	DMA Command register	
40	will specify if the channel is to cascade two DMA controllers	

- DMA Request register
- > DMA Mask register
- > DMA Mode register
- DMA Command register

50 are the long	gitudinal division of the disk.
> Tracks	
> Sectors	PG # 201
Blocks	
> None of given	
iracks are the circular divisio	on of the disk and the sectors are the longitudinal division of the disk
	acity of the disk according to the IDE interface is
➢ 504 MB	
> 80 GB	
➤ 127 GB	PG # 212
> 300 GB	
52.In partition table, first	t bytes contain code which loads the boot block of active partition.
> 128	
> 286	
> 446	PG # 218
≻ 500	
53.On a single disk there	e can be different Operating Systems.
≥ 2	
> 4	PG # 219
> 6	
≻ 8	
سب کچھ جانتا ہوں	عقل مند کہتا ہے میں کچھ نہیں جانتا جبکہ بے وقوف کہتا ہے کہ میں

54 is physical or absolute address.	
> <b>LBA</b> PG # 240	
> LSN	
> CHS	
None of the given	
55.The block is the first block on disk.	
> LSN =0	
> <b>LBA=0</b> PG # 240	
➢ Both LBA=0 and LSN=0	
<ul><li>None of the given</li></ul>	
56.A directory is collection of	
<ul> <li>Bios Parameter Blocks</li> </ul>	
<ul> <li>Drive Parameter Blocks</li> </ul>	
File Control Blocks	
> None of the given	
57.First cluster in user data area is numbered	in a FAT based systems.
> 0	
> 1	
> 2 PG # 258	
> 3	

58.Blocks for FAT can be accessed using \_

- > BPB
- > DPB
- ➢ FCB
- Both BPB and DPB.

59.In FAT12 to calculate the address or offset from index, we need to multiply it with \_\_\_\_\_

- > 1/2
- > 3/2 PG 267
- > 5/2
- ▶ 7/2

60.Using the root directory entry and the \_\_\_\_\_, we can access the contents of File.

- Reserved Blocks
- Number of FAT copies
- File Allocation Table(FAT) PG #269
- > None of the given

61.In FAT16 if FAT entry is between FFF0H to FFF6H then \_\_\_\_\_

- Cluster is available
- > It is a Reserved cluster
- > It is next file cluster
- ➢ It is a last file cluster

62.	needed to store a UNICODE character.
	Nibble
>	2 Bytes
	4 Bytes
>	Byte
63.	used for FCB in FAT 12 and FAT 16.
	N7111
>	Nibble
۶	Byte
۶	2 Bytes
≻	4 Bytes
64.	file system is used in CD's.
۶	None of the given
۶	Contiguous
>	Chained
$\blacktriangleright$	Indexed
65.	FAT based file system can store file name in form.

> ASCII

- > UNICODE
- > Both ASCII and UNICODE
- > None of the given

66.In case of \_\_\_\_\_\_ contents, the indexes of clusters of file are stored in MFT.

- Small files
- Large files
- Both small and large files
- None of the given

67.In memory map of first 1 MB of RAM, the higher \_\_\_\_\_ is called system memory.

- ▶ 64 KB
- ➢ 384 KB
- ➢ 640 KB
- None of the given

Memory map of the first 1MB of RAM. The first 640KB is called conventional RAM and the higher 384KB is called system memory

68.PC's operated on 20 bit address bus can operate in \_\_\_\_\_ mode.

- Real PG # 319
- Protected
- Both real and protected
- None of the given

خود کو تمہیں سے بڑھ کر کوئی اچھا مشورہ نہیں دے سکتا

69.Int 21H/52H returns the address of DOS internal data structures in ES: BX, the far address of the first MCB in memory lies \_\_\_\_\_\_ behind the address returned.

- > 2-bytes
- ➢ 4-bytes
- ➢ 6-bytes
- > 8-bytes

70.	In memory management, descriptor entry is of bytes.
>	6 <mark>4</mark>
۶	32
≻	8
>	16
71.	There are Control registers in 80386 and above systems.
>	2
>	4 PG # 331
	8
	16
72.	Control Registers are used for conveying certain control information for Addressing and Co-Processors.
>	Real Mode
>	Protected Mode PG # 331
۶	Virtual Mode
>	None of the given

73. The least significant bit of Control register	_ is PE-bit which can be set to enable Protected Mode Addressing.
> CRO	
> CR1	
> CR2	
> CR3	
74.CD command gives the of directory.	
> None of the given	
> One previous level	
> One next level	
Current path PG #282	

75.Cluster size is variable and can be measured in power of \_\_\_\_\_

 $\triangleright$ 2 16 4

> 8

سمی انسان کی خوبی کو پہچا نوں اور ایسے بیان کر د، لیکن اگر کمی کی خامی ال جائے تو یہاں تمہاری خوبی کا امتحان ہے۔ فرمان حضرت علیؓ

76. Who notifies the end of interrupt (EOI) to the programmable interrupt controller?

- > Programmer
- Microprocessor
- Operating system
- ➢ None of the given

77. Choose the correct statement to notify the interrupt controller about end of interrupt (EOI).

- Inportb(0x20,0x20)
- Outportb(0x20,0x20)
- Outportb(0x30,0x22)
- None of the given

78.Information about Pending interrupts are held by \_\_\_\_\_

- Interrupt Service Register
- Interrupt Mask Register
- None of the Given
- > Interrupt Request Register

79. BPB stands for \_

- BIOS parameter block
- BIOS processing block
- Base processing block
- BIOS partition block

80. The input frequency used by the interval timer is the \_\_\_\_\_\_signal generated by the clock generator.

- None of Given
- PCLK
- ACL
- ICP  $\geq$

81.BIOS DO NOT support

- LPT1  $\triangleright$
- LPT2 >
- LPT3 5
- LPT4  $\triangleright$

82.DTE is \_

Data terminal equipment PG #109 ≻

- Data transmitting equipment  $\triangleright$
- Dual terminal equipment  $\triangleright$
- None of the given.  $\triangleright$

83.Int 14H \_\_\_\_\_ can be used to send a byte.

- Service #0 >
- Service #1  $\geq$
- Service #2  $\triangleright$
- Service #3  $\geqslant$

جو شخص ناکامیوں سے ڈر کر بھاگتا ہے کامیابی اُس سے ڈر کر بھاگتی ہے

84.A single DMA can transfer \_\_\_\_\_ operands to and from memory in a single a bus cycle.

- > 8 bit
- ➤ 16 bit
- ➤ 32 bit
- ➢ 64 bbit

85.DMA does not work in \_\_\_\_\_ mode.

- Double Mode
- Block Transfer
- Demand Transfer
- None of the given

86. An addressable unit on disk can be addressed by three parameters \_\_\_\_\_

- head #, sector # and track #
- ➢ HD #, AH# and track #
- Hd0 #, sector # and track #
- None of the given

87.Each addressable unit has a unique combination of sec#, head# and track# as its \_\_\_\_\_\_ address.

- Both Physical and Logical
- None of the given
- Physical
- Logical

جو لوگوں کے سامنے فخر کرتا ہے وہ لوگوں کی نظروں سے گر جاتا ہے

88.In partition table, first bytes contain code which loads the boot block of active partition.
> 128
> 286
► 446
> 500
89.On a single disk there can be different Operating Systems.
> 2
> 4
> 6
> 8
90. The last partition table within the chain contains entry/entries about the logical drive.
<ul> <li>90. The last partition table within the chain contains entry/entries about the logical drive.</li> <li>Single</li> </ul>
> Single
<ul> <li>Single</li> <li>Double</li> </ul>
<ul> <li>Single</li> <li>Double</li> <li>Three</li> <li>Four</li> </ul>
<ul> <li>Single</li> <li>Double</li> <li>Three</li> </ul>
<ul> <li>Single</li> <li>Double</li> <li>Three</li> <li>Four</li> </ul>
<ul> <li>Single</li> <li>Double</li> <li>Three</li> <li>Four</li> <li>91.Partition Table can be read using the extended Services.</li> </ul>
<ul> <li>Single</li> <li>Double</li> <li>Three</li> <li>Four</li> <li>91.Partition Table can be read using the extended Services.</li> <li>13H</li> </ul>
<ul> <li>Single</li> <li>Double</li> <li>Three</li> <li>Four</li> <li>91.Partition Table can be read using the extended Services.</li> <li>13H</li> <li>14H</li> </ul>

92.File control block (FCB) is byte long.	
≻ 8	
▶ 16	
> 32	
▶ 64	
93 is collection of contagious blocks.	
> Cluster	
> Sector	
> File	
> Directory	
94.A FAT 12 table can have maximum values.	
> 1024	
> 2048	
➢ 4096	
None of given	-
2^12 entries maximum = 4096	
95. The first cluster number of file can be found in	
> BPB	
> DPB	
> FCB PG # 265	
None of the given	

96.In FAT12 if FAT entry is 000H then	
➢ It is a last file cluster	
<ul> <li>Cluster is available</li> </ul>	
> It is a Reserved cluster	
It is next file cluster	
97.Total number of clusters of FAT12 are	
> FF0 H	
> FFF H	
> FEF H	
FEE H         PG # 266	

is/are needed.

98.When we mark a file as deleted by placing 0xE5 then the chain of clusters in FAT is also replaced by \_\_\_\_\_

Þ	E5
۶	0
۶	1
۶	Ν
99.To	store a cluster in FAT 32 _

> Byte

> 2 Bytes

> 4 Bytes

> Nibble

100	keeps the back up of its boot block.
>	FAT 12
۶	FAT 16
۶	FAT 32
۶	None of the given
101.U	p to bytes can be used to store a file name in NTFS.
>	30
>	126
۶	254
۶	510
102.F	irst logical sector of NTFS partition is
>	DPB
۶	MFT
>	Boot sector
۶	None of the given
103.T	he LSN of first logical sector of NTFS partition is
>	0
>	1
۶	2
۶	3

104.Ir	n case of	_ the contents of file are store	ed in MFT.		
>	Small files				
>	Large files				
۶	Both small and la	arge files			
۶	None of the given				
105.Ir	nterrupt Descriptor	Table can have up to	_entries.		
>	64				
>	128				
>	<mark>256</mark>				
>	512				
106.T	here can be	different descriptors privilege	e levels.		
>	2				
>	4				
>	8				
~	10				
407 T	he least similiant	hit of Control as sister	is DE hit subjek som he so	t to another Depterto d Mod	A dunasing
107.1	ne least significant	bit of Control register	IS PE-bit which can be se	et to enable Protected Mode	e Addressing.
>	CR0	PG # 331			
۶	CR1				
>	CR2				
~	CR3				

108.Entry point of execution in EXE File can be	
From first instruction	
From last instruction	
Anywhere in the program PG # 335	
From anywhere in the middle	
109.In NTFS, Block # is the safest block to store the back up of boot block.	
> 8	
> 10 Not sure	
> 20	
> 6	
110.Size of single entry in Partition Table is	
> 512 bytes	
> 128 bytes	
> 64 bytes	
> 16 bytes	
111.MBR partition table can have entries at maximum.	
> 1	
> 2	
> 3	
> 4 Not sure	

112	is a data structure maintained by DOS in the boot block for each drive.
Þ	DPB
~	BPB PG # 242
~	FCB
>	None of the Given
113.H	Iidden blocks between the first physical block on each partition are used by for storing of data
>	User
>	Operating System
۶	BIOS
>	None of the Given
114.V	Which of the following data structure is NOT used in Operating System's File management?
۶	Memory Control Block PG # 06
۶	File Allocation Table
۶	Drive Parameter Block
>	File Control Block
115.I	nterrupt procedures are procedures.
>	ReentrantPG # 38
>	Non-Reentrant
>	Recursive
>	Virtual

116. The extension of a compiled TSR (Terminate and Study Resident) program should be \_\_\_\_\_

- > .EXE
- > COM
- > .CPP
- ▶ .C

to make a .C program a TSR program, you are required to generate a .COM file by using the following command in DOS prompt. bcc –EEXAMPLE.COM –IC:\BORLANDC\INCLUDE –LC:\BORLANDC\LIB EXAMPLE.C

عقل مند اپنے عیب خود دیکھتا ہے اور بیوقوفوں کے عیب دنیا دیکھتی ہے

Here, we are generating EXAMPLE.COM for of EXAMPLE.C program.

117. Choose the correct statement to notify the interrupt controller about end of interrupt (EOI).

- > Inportb(0x20,0x20)
- Outportb(0x20,0x20)
- $\triangleright$  Outportb(0x30,0x22)
- > None of the given

118.Information about Pending interrupts are held by \_\_\_\_\_

- Interrupt Service Register
- Interrupt Mask Register
- Interrupt Request Register
- None of the Given


119 Procedure can have parameters.		
Hardware Interrupt		
Software Interrupt		
Both Hardware and software Interrupt	PG # 10	
> None of the Given		
120.The Address of partition block on hard disk is		
head # =0, track # = 0 and sector # = 0		
> head # =0, track # = 0 and sector # = 1		
> head $\# = 0$ , track $\# = 1$ and sector $\# = 1$		
head # =1, track # = 0 and sector # = 1	PG # 42	
121.NMI Stand for		
Non Maskable Interrupt	PG #46	
Non Multitude Interrupt		
<ul> <li>Non Maskable Instruction</li> </ul>		
<ul> <li>None of Given</li> </ul>		
122. The interval timer is used to divide an input frequency.		
> True	PG # 68	
> False		
دماع سے بہتر ہے	بدصورت چېره بدصورت	

123. The PPI acts as an interface between the CPU and a parallel \_\_\_\_\_ . I/O device PG # 86  $\triangleright$ CPU  $\triangleright$ BUS  $\triangleright$ None of Given  $\triangleright$ 124.BIOS DO NOT support > LPT1 LPT2  $\triangleright$ LPT3  $\triangleright$ LPT4  $\triangleright$ 125.\_\_\_\_\_ is used to identify the cause of interrupt. Interrupt Enable register  $\triangleright$ Interrupt ID register Interrupt Status register >None of the given  $\triangleright$ 126. The bit \_\_\_\_\_\_ of Line control register in UART, if cleared will indicate that DLL is the data register. 1 3 5 7  $\geqslant$ 

127.Ir	nt 14H	can be used to send a byte	e.
>	Service # 0		
>	Service # 1	PG # 121	
~	Service # 2		
>	Service # 3		
Service	<mark>e of 14h include se</mark> i	rvice #1 which is used to so	end a byte and service #2 which is used to receive a byte
128.T	o access bettery po	wered RAM, only	ports are important from programming point of view.
~	70 and 71H	PG	# 141
~	71 and 72H	10/	
A	70 and 72H		
۶	72 and 73H		
129.T	he DMA requests t	o acquire buses through th	e signal.
~	HOLD	PO	G # 186
A	ACR		
>	ACK		
>	All of the given		
130	1150	ed to program various com	amon parameters of transfer for all the channels.
100			anon parameters of dansfer for an the chambers.
>	None of the above	2	
>	DMA Status Regi		
>	<b>DMA Command</b>		PG # 191
>	DMA Request Re	gister	

131.Bit # of mode register in	DMA determine the direction of a transfer.
× <b>3</b>	
> 2	
> 3	
> 4	
≥ 5	
132 will specify if the r	ext DMA transfer will happen as a single transfer, block transfer or demand transfer.
> DMA Request register	
DMA Mask register	
> DMA Mode register	
> DMA Command register	
133.Each addressable unit has a unic	ue combination of sec#, head# and track# as its address.
Both Physical and Logical	
> None of the given	
> Physical	PG # 202
> Logical	
134.Highest capacity of disk can be	accessed using BIOS functions is
➢ 128 MB	
➢ 256 MB	
> <mark>504 MB</mark>	PG # 211
➢ 127 GB	
en	1° 6° 1° 1° 6° ° 1 1 1 °
موسی نہیں ہو جانی	عقل مند آدمي اس وقت تک نہيں بولتا جب تک خا

135.DOS has built in limit of	blocks per cluster.			
10000				
> 32				
≻ 64				
> <mark>128</mark>	PG # 242			
> 256				
136.BIOS Parameter block is situated in Block.				
≻ <mark>Boot</mark>	PG # 242			
> Data				
<ul><li>Extended Data</li></ul>				
None of Given				
137.The block is the first block	ock on disk.			
> LSN =0				
≻ <mark>LBA=0</mark>	PG # 240			
➢ Both LBA=0 and LSN=0				
> None of the given				
138.Inside a boot block jump code pa	art occupies byte.			
100.mstde a boot block jump code pl				
> 5				
> 8				
> 11				
> 3	PG # 244			
8 1				
حت حاصل ہو	بہترین تجربہ وہ ہے جس سے نصیہ			




- ➢ FF0 H
- ≻ FFF H
- ➢ FEF H
- **FEE H** PG # 266

142.In FAT12 to calculate the address or offset from index, we need to multiply it with \_\_\_\_\_

PG# 267

143.T	otal number of cluster of FAT16 is
>	FFF0 H
>	FFFF H
>	FFEF H
>	FFEE H Page 272
144.T	otal fragments can be supported for storing long file names.
>	26
>	28
8	32
۶	48
145	used for FCB in FAT 12 and FAT 16.
۶	Nibble
>	Byte
4	2 Bytes
>	4 Bytes
146.T	o store a cluster in FAT 32 is/are needed.
۶	Byte
۶	2 Bytes
>	4 Bytes
>	Nibble



148.First logical sector of NTFS partition is \_\_\_\_\_

- > DPB
- > MFT
- Boot sector
- > None of the given

149.Extended memory can be accessed in \_\_\_\_\_ mode.

- ➢ Real
- > Protected
- Both real and protected
- None of the given

150.MCB is a \_\_\_\_\_ bytes data structure.

> 8
> 16 PG # 321
> 32
> 64

151.Real mode does not support \_\_\_\_\_ memory allocation system.

- Contiguous
- Non Contiguous
- Both Contiguous and Non Contiguous
- None of the given

152. There can be \_\_\_\_\_ different descriptors privilege levels.

153.In memory management, descriptor entry is of \_\_\_\_\_ bytes.

- 8
  16
  32
- ≻ <mark>64</mark>

154.For virus to propagate itself, it has to intercept interrupt

- ➢ 9H
- ≻ 11H
- ≻ <mark>13H</mark>
- ▶ 17H

خوبصورتی علم و ادب سے ہوتی ہے لباس و حسن سے نہیں

155.If	virus wants to be in memory in	ndependently, it should have its own
>	МСВ	
۶	PSP	
۶	EB	
۶	Both MCB and PSP	PG #334
156.S	ize of single entry in Partition 7	Cable is
>	512 bytes	PG#218
۶	128 bytes	
>	64 bytes	
۶	16 bytes	
157	is a data structure	e maintained by DOS in the boot block for each drive.
۶	DPB	
۶	BPB	PG#242
۶	FCB	
۶	None of the Given	
158.C	luster size is variable and can b	e measured in power of
>	2	PG#242
≻	16	
>	4	
۶	8	

159.Bit #	_ of Eflag is used for alignment check
<ul><li>12</li><li>14</li></ul>	
> 15 > <b>18</b>	PG # 164

160.Each addressable unit has a unique combination of sec#, head #, track # as its \_\_\_\_\_\_ address.

$\triangleright$	<b>Physical</b>	PG #202
-	I II y DICUI	

- Logical
- > Both
- > None

161.First cluster in user data is numbered in a FAT based system.

	0			
	1			
≻	2		PG #	258
≻	3			

162.BIOS services understand -----.

$\triangleright$	LBA	PG # 212

- > LSN
- Cluster #
- None

163. The first cluster number of a file can be found in------

- > BPB
- > DPB
- **FCB** PG # 265
- None

164.The size of I	-S Info block is
➢ 64byte	
➢ 128 byte	
➢ 256 byte	
> <mark>512 byte</mark>	PG # 300
165.In NTFS firs	st entries are reserved.
▶ 4	
▶ 6	
≻ <mark>16</mark>	PG # 303
> 32	

166.In memory map of first 1 MB of ram ,the first ------ is called conventional RAM.

$\triangleright$	64kb

- ➢ 384kb
- 640kb PG # 317
- None

167.In memory map of first 1 MB of ram ,the higher ------ is called system memory.

- ➢ 64kb
- **384kb** PG # 317
- ≽ 640kb
- > None

168. The ----- of boot block constitutes of BPB.

- ➢ Code part
- Data part PG # 242
- > Both
- ➢ None

169.H	Extende	d BIOS function make use of address
$\triangleright$	<b>LBA</b>	PG # 212
≻	CHS	
$\checkmark$	LSN	
Þ	None	

170.LBA address can be used in place of the CHS address.

- **True** PG # 235
- ➢ False

171.In FAT12, the maximum range of clusters is .....

- ➢ 0 ~ FEFH
- ▶ 1~ FEFH
- 2 ~ FEFH PG # 266
- ➤ 3 ~ FEFH

172.NTFS volume can be accessed directly in DOS.

➢ True

 $\triangleright$ 

False

PG # 310

173.Each partition information chunk is 16 bytes long and the last two bytes at the end of the partition table data part is the partition table signature whose value should be \_\_\_\_\_\_ indicating that the code part contains valid executable code.

- ➢ 00AA
- ▶ 0055
- ▶ 050A
- AA55 PG # 219

		H/52H service returns the address of DOS internal data structures in ES: BX	behind
≻	2-bytes		
۶	4-bytes	PG # 322	
$\triangleright$	6-bytes		
۶	8-bytes		
	30386 can 1 2	have control registers.	
>	5		
	3		
>	<mark>4</mark>	PG # 331	
176.7	The partitic	on table uses the extended service.	
N	1011	DC # 224	

- 13H PG # 234
- ▶ 14H
- ▶ 15H
- ▶ 16H

177. The entry point of execution in EXE File can be

- > Start of the first instruction
- Start of the last instruction
- > Anywhere in the Program PG # 335
- Can be in the middle of the program

انسان کے لئے بری صحبت سے بڑھ کر بری کوئی چیز نہیں

178.Using the \_\_\_\_\_ entry and the FAT we can access the contents of file.

- Reserved blocks
- Root Directory
  PG # 269
- Number of FAT copies
- None of the given

179.Control information in files is maintained using

- > BPB
- > DPB
- **FCB** PG # 256
- ► FPB

180.What will happen if NTFS volume is accessed in DOS?

- Convert it to FAT volume
- Nothing will happen
- Error of invalid media
  PG # 310
- None of the given

181.LSN of FS Info block is available at

- > BPB
- > FAT
- Root Directory
- $\blacktriangleright$  None of the given

خاموشی غصبے کا بہترین علاج ہے

182.DOS device drivers do not understand the data structures.
≻ FAT12
> FAT16
> FAT32
> NTFS PG # 310
183 is a collection of contagious blocks.
> Cluster PG # 242
> Sector
> Byte
➢ None of Given
184 used to determine the amount of conventional memory interfaced with the processor in kilobytes.
▶ INT 10 H
▶ INT 11 H
> INT 12 H PG # 162
≻ INT 13 H
185.Bit number of coprocessor control word is the Interrupt Enable Flag.
<ul> <li>7 PG #168</li> <li>8</li> <li>9</li> <li>10</li> </ul>
186 To distinguish 486 with Pentium CPUID Test is used

186.To distinguish 486 with Pentium CPUID Test is used.

True PG # 166

➢ False

187.Practically	_ entries are there in FAT 32.
▶ 2^26	
▶ 2^28	
▶ 2^30	
> 2^32 PG # 265	
and the second	
188.BPB stands for	

- **BIOS parameter block** PG # 243
- BIOS processing block
- Base processing block
- BIOS partition block

189. The keyboard input character scan code is received at \_\_\_\_\_ port.

- 60H PG # 179
- ▶ 61H
- ▶ 62H
- ▶ 63H

190.\_\_\_\_\_ is LED control byte.

- ➢ 0xFD
- **0xED** PG #181
- ➢ 0xFF
- ➢ 0xEE



191.\_\_\_\_\_means typematic rate will be sent in next byte.

- > 0xF3 PG # 180
- ➢ 0xF4
- ➢ 0xF5
- ➢ 0xF6

192.Keyboard uses port \_\_\_\_\_ as status port.

- 64H PG # 177
- ▶ 66H
- ▶ 67H
- ▶ 69H

193.The keyboard can perform \_\_\_\_\_\_ serial I/O.

- ➢ asynchronous
- synchronous
- > Multiple
- Single

194.Bit number 2 of port 64H Status register used for output buffer full.

- ➢ True
- ➢ False

195.Bit number \_\_\_\_\_ can declares the parity error of port 64H Status register.

- ▶ 4
- > 5
- > 6
- > 7

196.Bit r	umber of port 64H Status register used for input buffer full.
> 0	
> 1	
▶ 2	
> 3	
197.Disa	dvantage of FAT32 is
> La	rge disk size can be managed in FAT32
> Cl	uster size is reduced
> Int	ernal fragmentation is reduced
> <mark>V</mark> e	ry large table PG # 299
198. Max	imum possible entries in FAT12 are
> 10	24
> 20	48
> <mark>40</mark>	96 PG # 264
> 65	536

- 199. What will be the value of the word located at 1Fh in DPB when number of free clusters on drive is not known?
  - ➢ 0000H
  - ▶ 1111H
  - **FFFFH** PG # 250
  - $\triangleright$  None of the given.



200.Jump code part contains bytes in boot block.
> 3 PG # 302
> 5
> 8
▶ 11
201. Operating system name contains bytes in boot block.
> 3
▶ 5
> 8 PG # 257
> 11
202.File can be viewed as organization of data.
> Physically
Logically PG # 256
Both logically and physically
None of the give
203 is used to read a block against its LSN.
> absread() PG # 247
> abswrite()
> lsnread()
None of the given

204. File can be \_\_\_\_\_ viewed as collection of clusters or blocks.

- Physically PG # 256
- ➢ Logically
- Both physically and logically
- > None

205. When we talk about FAT based file system, in user data area first cluster number is \_\_\_\_\_

0
1
2 PG # 258
None of the given

206. Cluster number can also be referred as block number.

- ➢ True
- False PG # 258

207. To access the block within cluster using BIOS services the cluster number should be converted into

- > CHS
- > LBA
- **LSN** PG # 258
- ➢ None of the given

208.What will be the value of DL register when we are accessing C drive using undocumented service 21H/32H?

0
1
2

**3** PG # 249

209. The directory structure of DOS is like \_\_\_\_\_

- Array
- **Tree** PG # 256
- Linked list
- None of the given

210.Control information about files is maintained using \_\_\_\_\_

- > BPB
- > DPB
- **FCB** PG # 256
- ► FPB

211.When LSN is equal to zero (0), it means \_\_\_\_\_

- First block of the disk
- First block of the logical drive PG # 240
- First block of hidden blocks
- None of the given

212.In FAT32, lower \_\_\_\_\_ bits are used.

- ▶ 26
- **28** PG # 292
- > 30
- > 32

213.\_\_\_\_\_ is relative address with respect to the start of Logical Drive.

- > LBA
- **LSN** PG #240
- > CHS
- ➢ None of the given

214.The practical limit of blocks per cluster is \_\_\_\_\_.
32 blocks per cluster
64 blocks per cluster PG #242
128 blocks per cluster
256 blocks per cluster
215.In dos we have limit of \_\_\_\_\_.
128 blocks per cluster PG #242
256 blocks per cluster PG #242
32 blocks per cluster

➢ 64 blocks per cluster

216. Highest capacity physical capacity of the disk according to the IDE interface is \_\_\_\_\_

- 127 GB PG # 212
- ➤ 100 GB
- \_\_\_\_
- ➢ 80 GB
- ➢ 300 GB

217.Partition Table can be read using the extended \_\_\_\_\_\_ Services.

- **13 H** PG # 234
- ≻ 14 H
- ▶ 15 H
- None of given

218.In Protected Mode, the segment registers are used as \_\_\_\_\_

- Descriptor
- Selector PG # 326
- All of the given choices
- None of the given choices

219.To access drive parameter block we use undocumented service
➢ 09H/32H
> 11H/32H
> 17H/32H
> 21H/32H PG # 249
220 is an absolute address relative to the start of physical drive.
> LBA PG # 240
> LSN
> CHS
None of the above
221.Boot block consists of bytes.
> 64
N 100

- ▶ 128
- ▶ 256
- **512** PG # 242

222. The DMA requests to acquire buses through the \_\_\_\_\_\_ signal.

- **HOLD** PG #186
- > ACR
- > ACK
- ➢ None of Given

اس سے پہلے کہ تمہیں شہوت فتنے میں ڈالے نکاح کرلو

223.The keyboard device writes a co	ode 0xFA on the port 60H to indicate that the
Input buffer is full	
> Byte has been received prop	erly PG # 179
Output buffer is full	
None of the given	
224.A single DMA can transfer	operands to and from memory in a single a bus cycle.
> <mark>8-bits</mark> PG # 186	
> 16-bits	
> 32-bits	
> 12-bits	
225.In FAT12, to calculate the addre	ess or offset from index, we need to multiply it with
> 1/2	
> 3/2	PG #267
> 5/7	
> 7/2	
226 Register can be used transfer mode.	to show that the channel is single transfer, block transfer or demand
DMA Command register	
DMA Request Register	
DMA Mode Register	

> DMA controller Register PG #187-188

227. When we mark a file as deleted by placing 0xE5 then the chain of clusters in FAT is also replaced by

- ≻ E5
- > 1
- O PG # 79
- > N

228.Cluster size is reduced in \_\_\_\_\_

- ► FAT12
- ➢ FAT16
- FAT32 Click here for detail
- None of the given

229.In FAT32 \_\_\_\_\_ root directory entries are there.

- ▶ 128
- > 256
- ▶ 512
- None of the given <u>Click here for detail</u>

230.If a file is having more than one cluster then it will be managed by \_\_\_\_\_

بری صحبت سے تنہائی بہتر ہے اور تنہائی سے نیک صحبت بہتر ہے

- ➢ FAT
- > BPB
- DPB
- None of the above

231.Internal fragmentation is reduced in

- ➤ FAT12
- FAT16 Click here for detail
- ➢ FAT32
- None of the given

232.For supporting long file names, \_\_\_\_\_\_ fragments can be supported.

- ▶ 12
- ▶ 20
- ▶ 26
- > 32

233.To store a cluster in FAT 32 \_\_\_\_\_ is/are needed.

- Nibble
- > Byte
- ➢ 2 Bytes
- 4 Bytes <u>Click here for detail</u>

234.If a file size is 12K and the size of the cluster is 4K then \_\_\_\_\_ clusters are used for the file.

2
3
4

> 5

ایماندار کو غصبہ دیر سے آتا ہے اور جلدی دور ہو جاتا ہے

235.We can access the contents of File by using the root directory entry and \_

- Reserved Blocks
- > Number of FAT copies
- **File Allocation Table (FAT)** PG # 269
- None of the given

236.FAT based file system can store file name in \_\_\_\_\_\_ form.

- > ASCII
- > UNICODE
- Both ASCII and UNICODE
- None of the given

237.Drive parameter block is derived from \_

- ➢ FCB
- ≻ FAT
- **BPB** PG # 249
- > CPB

238.We can access Blocks for FAT using \_\_\_\_\_

- BPB
- DPB
- > FCB
- Both BPB and DPB

جھوٹ انسان اور ایمان دونوں کا دشمن ہے

239.I	f we kn	ow the cluster number, we can access the blocks within the cluster using BIOS services directly.
$\triangleright$	<b>True</b>	PG # 258
$\succ$	False	
240		<u>is an internal data structure of DOS and resides in main memory.</u>
≻	BPB	
۶	DPB	
$\triangleright$	CPB	
>	None	of the given. <u>Click here for detail</u>
241.T	The size	of DPB data structure is bytes.
≻	16	
≻	32	
≻	64	
۶	<b>128</b>	<mark>click here for detail</mark>
242.7	The size	e of FCB data structure is bytes.
	> <mark>16</mark>	Click here for detail
	> 32	
	▶ 64	
	> 128	3
243.A	Advanta	ages of FAT32 is/are
≻	Large	disk size can be managed in FAT32
۶	<b>Clust</b>	er size is reduced <u>Click here for detail</u>
≻	Intern	al fragmentation is reduced
۶	All of	the given
	ا ہے	ایماندار کو غصبہ دیر سے آتا ہے اور جلدی دور ہو جات

## 244.\_\_\_\_\_ file system keeps the backup of its boot block.

- ➤ FAT12
- ➢ FAT16
- FAT32 <u>Click here for detail</u>
- ➢ None of the given

245.To store a UNICODE character \_\_\_\_\_ is/are needed.

- > Nibble
- > Byte
- 2 Bytes
  <u>Click here for detail</u>
- ➢ 4 Bytes


246.\_\_\_\_\_ is the first block on disk.

- ➤ LSN =0
- **LBA=0** PG # 240
- ► LBA=1
- ➢ Both LBA=0 and LSN=0

247.If FAT entry is between FFF0H to FFF6H in FAT16 then \_\_\_\_\_

- Cluster is available
- It is a Reserved cluster PG # 272
- It is next file cluster
- ➢ It is a last file cluster

خود کو تمہیں سے بڑھ کر کوئی اچھا مشورہ نہیں دے سکتا



249.A file has 2 clusters and the size of cluster is 4K. What will be the size of file?

- ➢ 2K➢ 8K
- ▶ 16K
- ➤ 32K

250.In NTFS, Backup of boot block is stored at block # \_\_\_\_\_

- ▶ 2▶ 6
- 0
- ≻ <mark>8</mark>
- ▶ 10

251.The interval timer can operate in \_\_\_\_\_ modes.

- ➢ Five
- > Seven
- > Four
- **Six** PG # 72

252.File control block (FCB) is \_\_\_\_\_ byte long.

۶	<mark>32</mark>	<u>Click here for detail</u>
۶	64	
	16	
۶	128	

- 253.DOS command \_\_\_\_\_\_ which gives the status of the memory and also points out which memory area occupied by which process.
  - **mem/d** PG # 13
  - ➤ mem/e
  - ➤ mem/m
  - None of the given

254.Each entry in the IVT is \_\_\_\_\_ in size.

- 4-bytes PG # 12
- ➢ 6-bytes
- ➢ 8-bytes
- 2-bytes

255. The tail value of the keyboard buffer should be examined to get to the \_\_\_\_\_ of the buffer.

- Start PG # 56
- > End
- > Middle
- None of given

256.Usually interrupt procedures are reentrant procedures especially those interrupt procedure compiled using C language compiler are reentrant.

- **True** PG # 38
- > False

جو شخص ناکامیوں سے ڈر کر بھاگتا ہے کامیابی اُس سے ڈر کر بھاگتی ہے

257		is Disk interrupt.
>	10H	
>	11H	
≻	<b>13H</b>	PG # 42
$\triangleright$	14H	

258.In parallel communication, the maximum numbers of bits we can send between two computers are

- > 2-bits
- ➤ 4-bits
- ➢ 6-bits
- 8-bits

259.14h include \_\_\_\_\_\_ which is used to send a byte.

- ➢ Service #0
- Service #1 PG # 121
- Service #2
- Service #3

260. The status register \_\_\_\_\_ is the main control register.

- **B** PG # 146
- ► A
- ≻ C
- > D

261.\_\_\_\_\_ is used to identify the cause of interrupt.

- Interrupt ID Register PG # 116
- PC Register
- > AC Register
- ➢ None of All These

262.In NTFS, up to cha	racters are used to store files names,
▶ 30	
▶ 48	
> 255 PG # 283	
> 510	

263.A cluster is a collection of contiguous \_\_\_\_\_.

- **Blocks** PG # 242
- Sectors
- > Bytes
- ➢ None of Given

264.In BPB, root directory is saved in \_\_\_\_\_

- Cluster#0
- ➢ Cluster#1
- ➢ Cluster#2
- ➤ Cluster#3

265.In NTFS, total sizes of MFT entries are \_\_\_\_\_

- 16-bytes PG # 303
- ➢ 20-bytes
- ➤ 26-bytes
- ➤ 32-bytes

266.In NTFS, \_\_\_\_\_\_ store the contents of file.

## Both small & large file Record

- Small record
- Large Record
- ➢ None of given

267.In NTFS, contents and indexed of file is stored in \_

- Small record
- Large Record
- Both small & large file Record
- None of given

268. Total No. of bytes that can be stored in Keyboard Buffer is\_\_\_\_\_.

≻	16
۶	<b>32</b> PG #54
۶	64
≻	128
269.E	BIOS supportUARTS as COM ports.
≻	6
$\triangleright$	4 PG #113
۶	3
۶	2

270.DCE stands for \_\_\_\_

Data communication equipment PG # 109

.

- Distributed Computing Environment
- Data Communications Equipment
- Data Carrier Equipment

271.In counter register bit no. 3 changes its value between 0 and 1 with in \_\_\_\_\_clock cycles

1
2
4
16 PG #69

272	2.Ir	neach byte is needed to be encapsulated in start and end.
2		Synchronous communication
2		Asynchronous communication PG # 106
2		Both
2		None of given
273	8.T	"he service # is not used in any interrupt.
2		01
2		02
2		03
2		FF
274	If	we want to send printing on the printer then we have to perform following steps.

Initialize printer

- Read Status
- Check Error
- All of the given

275.If printer is \_\_\_\_\_ then printer sends back the ACK signal to the printer interface

- idle PG # 97
- > busy
- > Out of paper
- ➢ None of the given

## 276.DSR stands for \_

- Data set ready
  PG # 111
- Data service ready
- Data stock ready
- $\blacktriangleright$  None of the given

277.At IRQ 7 Interrupt # \_\_\_\_\_ is used.

- ➢ 0x0A
- ➢ 0x0B
- ➢ 0x0C
- 0x0F PG # 95
- 278. The memory addresses of COM ports remain same for all computers
  - ➤ True
  - False
- 279.In keyboard status byte bit no. 2 and 3 are used for ctrl and alt keys respectively. which of the following condition is used to check that Ctrl + Alt keys are pressed. Where: unsigned char far \* scr = (unsigned char far \*)(0x00400017);
  - ➢ if (((\*scr)&12)==12)
  - ➢ if (((\*scr)&8)==8)
  - ▶ if (((\*scr)&4)==4)
  - ➢ if (((\*scr)&2)==2)

280.In case of synchronous communication a timing signal is required to identify the start and end of a bit.

- True PG # 105
- ➢ False
- 281.The baud rate is set in accordance with the divisor value loaded within the UART internal registers base +0 and base +1.
  - True PG # 114
  - False

عقل مند آدمی اس وقت تک نہیں ہولتا جب تک خاموشی نہیں ہو جاتی

_		
	282.S	oftware based flow control make use of control characters
	≻	Xon
	$\triangleright$	XOFF
	$\triangleright$	Both PG # 135
	≻	None
	283	is used to read time from RTC
	۶	<b>1A\02H</b> PG # 137
	≻	1A\03H
	≻	1A\04H
	۶	1A\05H
	284.I	nt service 0 can be used to set the line parameter of the UART or COM port.
	≻	14H PG # 119
	⊳	15H
	≻	13H
	≻	None of the given option
	285.V	When LBA is equal to zero (0), it means
	>	First block of the disk PG # 240
	۶	First block of the logical drive

- ➢ First block of the hidden block
- $\blacktriangleright$  None of the given

286.In IRQ2 and IRQ3 which one has the highest priority?

- Can't be determined
- Both have same priority
- ► IRQ3
- IRQ2 PG # 47

287.Following is not a method of I/O

- Programmed I/O
- Interrupt driven I/O
- Hardware Based I/O PG # 4
- None of given

288.It is possible to perform I/O operations from three different methods.

- ➢ True PG # 7
- ➢ False

289. The Function of I/O controller is to provide \_

- I/O control signals
- Buffering
- Error Correction and Detection
- All of given
  PG # 5

290. Which of the following are types of ISR \_\_\_\_\_

- BIOS (Basic I/O service ) ISR
- DOS ISR
- ISR provided by third party device drivers
- All of the given PG # 13

291.Interrupt service number is usually placed in \_\_\_\_\_ register.

- ≻ CH
- ≻ CL
- **AH** PG # 26
- > AL

خوبصورتی علم و ادب سے ہوتی ہے لباس و حسن سے نہیں

## 292.NMI Stand for

- Non Maskable Interrupt PG # 46
- Non Multitude Interrupt
- Non Maskable Instruction
- ➢ None of Given

293.A single interrupt controller can arbitrate among \_\_\_\_\_ different devices.

47

4	
6	
8	<b>PG</b> #
10	

- 294. The microprocessor package has many signals for data. Below are some incorrect priority order (Higher to Lower).
  - Reset,Hold,NMI,INTR PG # 46
  - NMI, INTR, Hold, Reset
  - > INTR,NMI,Reset,Hold
  - None of the Given

295.The following command "outportb (0x61,inportb(0x61) & 0xFC);" will

- ➤ Turn on the speaker
- **Turn off the speaker** PG # 75
- Toggle the speaker
- None of the given

296. The following command "outportb (0x61, inportb(0x61) | 3);" will \_\_\_\_\_

- **Turn on the speaker** PG # 74
- ➢ Turn off the speaker
- Toggle the speaker
- $\blacktriangleright$  None of the above

297. The PPI acts as an interface between the CPU and a parallel			
>	I/O device PG # 83		
$\triangleright$	CPU		
>	BUS		
>	None of Given		
298.BIOS DO NOT support			
~			
	LPT1		
	LPT2		
	LPT3 LPT4 PG # 91		
299	bit is cleared to indicate the low nibble is being sent.		
>	D1		
≻	D2		
۶	D3		
>	D4 PG # 104		
300.The bit of Line control register in UART, if cleared will indicate that DLL is the data register.			
×	1		
	3		
	5 7 PG # 114		
301	file system is used in NTFS based systems.		
>	Contiguous Chained		
Indexed			
>	None of the given		

302.Communication between keyboard and keyboard controller is \_

- Asynchronous serial
- Synchronous serial PG # 77
- Parallel communication
- $\blacktriangleright$  None of the given

303.In NTFS, boot sector is stored at

- First and 6th sector
- First and Last sector
- Only at Last sector
- Only at First sector

304.Standard PC operates in two modes in terms of memory which are

- Real mode and Extended Mode
- Base mode and Memory Mode
- None of the given
- Real mode and protected mode PG # 6

305.IVT is a table containing \_\_\_\_\_ byte entries each of which is a far address of an interrupt service routine.

2		
4		PG # 20
8		
16		

306.Each paragraph in keep function is \_\_\_\_\_ bytes in size.

۶	4	
$\triangleright$	8	
۶	<mark>16</mark>	PG # 24
	32	

307.A software interrupt does not require EOI (End of interrupt.		
≻ <mark>True</mark>	PG # 49	
➢ False		
308.To store each	character in keyboard buffer bytes are required.	
> 2	PG # 54	
▶ 4		
> 6		
> 8		
309.Interrupt	is empty; we can use its vector as a flag.	
➢ 9H		
▶ 13H		
▶ 15H		
≻ <mark>65H</mark>	PG # 65	
310.Command reg	gister is an bit register	
≻ 4		
≻ <mark>8</mark>	PG # 71	
▶ 16		
▶ 32		
311.How many b	oytes can be used to store a file name in NTFS?	
▶ 128		
> 255		
> 510		
▶ 1024		
\$ 1: 1	. C. Sin in all all C. Sin in a character of a state of the second	
ہواں حامو سی ہے	ہر چیز کی ایک پہچان ہوتی ہے اور عقلمند کی پہچان غوروفکر کرنا ہے اور غوروفکر کی پ	

312	is the first logical sector of NTFS partition.
> [	<b>DPB</b>

- > MFT
- Boot sector
- > None
- 313.In boot block BIOS parameter block starts from 03H
  - ▶ 05H
  - ▶ 08H
  - > **0BH** PG # 302

314.IN NTFS, FAT and root directory is replaced by

- ➢ FCB
- **MFT** PG # 301
- Hidden blocks
- Boot sector

315.Block # 2 is the safest block to store the backup of boot block.

- > True
- False

316. The keyboards interface as discussed earlier uses the IRQ0 and the port 64H as data port.

- ➤ True
- False

317.FAT12 will have 12-bit wide entries and can have 2^12=4096 entries maximum

- True
- ➢ False

- 318.In order to produce the sound from PC internal Speaker we have to load the\_\_\_bit divisor value at the \_\_\_port.
  - ▶ 8, 0x21
  - ▶ 16, 0x42
  - ➢ 32, 0x22
  - ▶ 64, 0x32

319.DMA stands for\_\_\_\_

Direct Memory Access

**PG # 4** 

- Distinct Memory Access
- Direct Module Access
- Direct Memory Allocation

## 320.UART stands for\_\_\_\_

- Universal Asynchronous Receiver Transmitter PG # 107
- Universal Adjustment and Realigning Tool
- Unconventional Assisted Recovery Team
- None of these

321.Interrupt Vector Table (IVT) in short is a \_\_\_\_\_ bytes sized table.

- ▶ 1024
- ▶ 2048
- > 3072
- ▶ 4096

322.Hardware Interrupts are \_\_\_\_

- Preemptive
- Non-Preemptive
- Both Preemptive and Non-Preemptive
- None of Given

PG # 10

PG # 48

323.Timer interrupt is a	-			200
Hardware Interrupt	PG # 28			
<ul> <li>Software Interrupt</li> </ul>				
Both of these				
None of These				1.0
324.The keyboard makes use of ir	nterrupt number	for its input operation	s.	
> 9	PG # 34			
▶ 10				1. 1.
> 11				
▶ 12				
325.Register can be used to divide	e frequency is	-		
Counter Register	PG # 69			1.11
<ul> <li>Accumulator Register</li> </ul>				1.00
> None of these				
326.Which port is known as Data	Port			2.35
≻ <mark>60H</mark>	PG # 177			
≻ 61H				
▶ 64H				0012
➢ 69H				
327.LPTs can be swapped.				6.600
≻ <mark>True</mark>	PG # 92			
➢ False				
328.PPI is used to perform paralle	l communication			
True	PG # 81			
> False				

329is used to contr	rol the printer via the BIOS
➢ Int 16H	
➢ Int 17H	<b>PG # 84</b>
➢ Int 18H	
▶ Int 19H	
330. There are two main types o	f interrupts namely
PC based and Window bas	sed
Hardware based and Kern	al based
Hardware interrupts an	d Software interrupts PG # 10
None of the given	
331.To set the interrupt vector r	neans is to change the double word sized interrupt vector within the IVT.
≻ <mark>True</mark>	PG # 22
> False	
332. The service number is usual	lly placed in the register.
> AL	
> CL	
> AH	PG # 26
> AX	
333. The keyboard makes use of	interrupt number for its input operations.
> 9	PG # 34
≻ 10	
▶ 11	
▶ 12	
ی دور بو جاتا ہے	ایماندار کو غصبہ دیر سے آتا ہے اور جلد

334.The service	is called the keyboard hook service.
➢ 15H/2FH	
≻ <mark>15H/4FH</mark>	PG # 44
▶ 15H/FFH	
335.The BIOS inte	errupt can be used to configure RTC.
> 1AH	PG # 136
> 2AH	and the second
> 3AH	
➤ 4AH	
336.PPI stands for	
<ul> <li>Parallel Prog</li> </ul>	grammable interface
Peripheral 1	Programmable interface PG # 76
	nmable interface
> None of the	given
337.Int	is used to control the printer via the BIOS.
> <u>17H</u>	PG # 84
► 18H	
≻ 20H	
➤ 21H	
338.Counter regist	er can be used to divide clock signal.
≻ <mark>True</mark>	PG # 69
➢ False	

دنیا میں سب سے مشکل کام اپنی اصلاح اور سب سے آسان کام دوسروں پر نکتہ چینی کرنا ہے

339.The bit number	of the coprocessor control word is the interrupt enable flag.
> 7	PG # 168
> 8	
> 9	
> 6	
340.There are	kinds of serial communication.
> 2	PG # 105
> 3	
> 4	
> 5	
341 store the	base address for LPT1.
➤ 40:00H	
➢ 40:02H	
≻ <mark>40:08H</mark>	PG # 92
➢ 40:1AH	

342. The amount of memory above conventional memory (extended memory can be determined using the service \_\_\_\_\_.

- I5H/88H PG # 162
- ▶ 16H/88H
- ▶ 17H/88H
- ➢ 21H/88H

343. The output on the monitor is controlled by a controller called \_\_\_\_\_\_ within the PC.

Video controller PG # 30

- Bus controller
- Ram controller
- None of the given

344.Interrupt 9 usually reads the \_\_\_\_\_\_ from keyboard. ➢ ASCII code Scan code **PG # 34**  $\triangleright$ Both ASCII and Scan code  $\geq$  $\succ$  None of the above 345.NMI Stand for Non Maskable Interrupt **PG # 46** Non Multitude Interrupt Non Maskable Instruction  $\geq$ ➢ None of Given 346.A single interrupt controller can arbitrate among \_\_\_\_\_ different devices. 4  $\triangleright$  $\triangleright$ 6 PG # 47  $\triangleright$ 8 > 10 347. The microprocessor package has many signals for data. Below are some in Correct priority order (Higher to Lower).

- **Reset, Hold, NMI, INTR** PG # 46
- NMI, INTR, Hold, Reset
- INTR,NMI,Reset,Hold
- None of the Given

348.The \_\_\_\_\_\_function initialize the COM port whose number is passed as parameter using BIOS services.

- Initializecom()
- Initialize()
  PG # 125
- Recievechar()
- None of these option

349.There are two type of communication synchronous and Anti Synchronous➢ True

**False PG # 105** 

350.REGS is a Union

- True
- ➢ False

351.Keyboard Status Byte is located at the address

- ➢ 0040:0000H
- ➢ 0040:0013H
- ➢ 0040:0015H
- 0040:0017H
  PG # 29

352.If we use keep (0, 1000) in a TSR program, the memory allocated to it is

- ➢ 64000 bytes
- ➤ 32000 bytes
- 16000 bytes
- > 80000 bytes

353.Maximum number of interrupts in a standard PC is

64	
128	
<mark>256</mark>	PG #1 0
512	

354. The ------ function receive a byte and COM port number is passed as parameter using BIOS service

- Receivebyte ();
- ➢ Receive ();
- Receivechar (); PG # 125
- None of the given option

	whene ne end of commun	ver receive indicates the start of communication whenever receive indicates
>	XON\XOFF	PG #135
>	XOFF\XON	
>	XON\YOFF	
>	YON\XOFF	
356	is us	sed to set time from RTC
>	1A\02H	
>	1A\03H	PG #138
►	1A\04H	
$\triangleleft$	1A\05H	
		ector means to change the double word sized interrupt vector within IVT.
~	True	PG #22
	False	
358.I	f keyboard buffer	is empty the head and tail points at the same location.
>	True	PG #55
≻	False	
359.8	Standard PC can h	ave PPI.
$\triangleright$	1	
>	4	PG #84
>	8	
>	16	
360.E	By cascading two	DMAs bits can be transferred.
×	4	
	8	
	16	PG #186

> 32

361.PPI interconnection bits is cleared to indicate low nibble is being sent.	
> D1	
➢ D2	
> D3	
> <b>D4</b> PG # 101	
362.Display device (Monitor) performs I/O.	
➢ memory mapped PG #30	
> Isolated	
➢ Both of above	
> None of these	
363. Timer interrupt occurs times every second by means of hardware.	
▶ 18.2 PG # 28	
▶ 16.2	
▶ 15.2	
▶ 14.2	
364.An I/O device cannot be directly connected to the busses so controller is placed between CPU and I/O.	
➢ True PG # 83	
> False	
365.Tail of keyboard should get to get the start of buffer.	
➤ True PG # 55	
> False	
366 No. of bytes are used to store the character in the keyboard buffer.	
▶ 1	
> 2 PG # 54	
≻ 4	
> 8	

367.We have set the bit No. 7 of IMR(Interrupt Mask Register) to unmask the Interrupt so that interrupt can occur at \_\_\_\_\_ line.

## ➢ 0xf ,IRQ 7

- ➢ 0xa, IRQ 6
- ➢ 0x8, IRQ 5
- ➢ 0x6, IRQ 2

368.If we want to produce the grave voice from speaker phone then we have to load the \_\_\_\_\_ divisor values at Port \_\_\_\_\_.


- ➢ high, 0x42
- ➢ low, 0x22
- ➢ high, 0x22
- ➢ low, 0x42

369.On the execution of IRET instruction, number of bytes popped from stack is

- ➤ 4 bytes
- ➢ 6 bytes
- 8 bytes
  <u>Click here for detail</u>
- > 10 bytes

370.If CPUID instruction is not present then the processor can be a

- 486 processor PG # 166
- ➢ 386 processor
- ➢ 286 processor
- All of the above



371.Extended memory is available if the processor is of the type \_

> AT

PG # 171

- > XT
- All of the given choices
- $\triangleright$  None of them

372. The built in mechanism within the UART for error detection is\_\_\_\_\_

- ➢ hamming code
- parity
  PG # 107
- CRC16 (cyclic redundancy check 16 bit )
- CRC32 (cyclic redundancy check 32 bit )
- 373.If three Programmable interrupt controllers are cascaded then how many interrupt driven hardware IO devices can be attached \_\_\_\_\_\_
  - ▶ 12
  - > 18
  - ≥ 23
  - > 24 PG #48

374.Int 14H\_\_\_\_\_ can be used to send a byte

- ➢ Service#0
- Service#1 PG #121
- ➢ Service#2
- None of the given option.

375.Int 14H \_\_\_\_\_ can be used to set the line parameter of the UART or COM port.

- Service # 0
  PG # 119
- Service # 1
- Service # 2
- None of the given options

376.I	nt 14H	can be used to receive a byte.
$\checkmark$	Service # 0	
$\triangleright$	Service # 1	
>	Service # 2	PG # 121
۶	None of the give	n options
377.7	Гhe	_ function simply enables the self test facility within the modem control register
≻	STOn()	
>	SelfTest()	
Þ	SelfTestOn()	PG # 127
≻	None of these	
378	is a devi	ce incorporated into the PC to update time even if the computer is off.
۶	Clock counter	
۶	ROM	
۶	Clock	and the second
4	Real time clock	PG # 136
379.I	nterrupt is	used to get or set the time.
>	0AH	
>	1AH	PG #136
~	2AH	
>	3AH	
380.	is used to see	et time.
~	1A/02H	
~	<b>1A/03H</b>	PG # 138
~	1A/04H	
>	1A/05H	

381.----- is used to read date from RTC

- ▶ 1A\02H
- ➢ 1A\03H
- IA\04H
  PG # 138
- ➤ 1A\05H

382. \_\_\_\_\_whenever received indicates the start of communication and \_\_\_\_\_\_ whenever received indicates a temporary pause in the communication.

- **XON & XOFF** PG # 135
- XOFF & XON
- > XON & YOFF
- > YON & XOFF

383.The\_\_\_\_\_\_ function uses the COM port number to receive a byte from the COM port using BIOS services.

- recievebyte()
- ➢ initialize ()
- > receive()
- recievechar() PG # 125

384.In self test mode the output of the UART is routed to its input.

- True PG # 117
- ➢ False

385.Only \_\_\_\_\_ ports are important from programming point of view.

- **70 and 71H** PG # 141
- ➢ 71 and 72H
- ➢ 70 and 72H
- ➢ 72 and 73H

386. The BIOS interrupt 0x1AH can be used to configure real time clock

- > True
- PG # 136
- ➢ False

Note: Give me a feedback and your Suggestion also If you find any mistake in mcqz plz inform me Viva Contact us Page on our Site. And tell me your answer with references.

For More Solved Papers By Arslan Visit Our Website: <u>Www.VirtualUstaad.blogspot.com</u>



Winning is not everything, but wanting to win is everything..... Go Ahead..... Best Of Luck !